



Honeywell

DC311XX
DC313XX


GB Contents DE Inhalt FR Contenu NL Inhoud FI Sisältö
DK Indhold IT Contenuto ES Contenido PT Conteúdo
GR Περιεχόμενα SE Innehåll





GB Getting started DE Erste Schritte FR Démarrage NL Aan de slag FI Aloitusopas DK Kom i gang
IT Operazioni preliminari ES Para comenzar PT Para começar PT Para começar PT Para comenzar
GR Πρώτα βήματα SE Kom igång






GB Optional features **DE** Optionale Funktionen
FR Options disponibles **IT** Opzioni **FI** Valinnaiset ominaisuudet
DK Valgfrie funktioner **PT** Funzionalità opzionali
ES Opciones disponibles **PT** Funções opcionais
GR Προαιρετικές λειτουργίες πρόσθιτων **SE** Möjliga funktioner



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	●	●					●	●
	●	●	●		●		●	●
	●	●	●	●	●	●	●	●



GB Linking **DE** Einlernen **FR** Programmation
NL Verknüpfung **FI** Linkittäminen **DK** Forbinde
IT Collegamento **ES** Enlace **PT** Länkning
PT Programação **GR** Ούνδεση **SE** Länkning











GB Trouble shooting **DE** Fehlerbehebung **FR** Dépannage **NL** Probleemoplossing
FI Vianmääritys **DK** Problemlösning **IT** Risoluzione dei problemi **ES** Solución de problemas **PT** Resolução de problemas **GR** Αντιμετώπιση προβλημάτων **SE** Felsökning

livewell.honeywell.com



L430S





GB Trouble shooting DE Fehlerbehebung FR Dépannage NL Problemplossing
 FI Vianmääritys DE Problemlösung IT Risoluzione dei problemi ES Solución de
 problemas PT Resolução de problemas GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com



32305352-003 Rev_A